

| VHF PROCEDURES  | REPORTS  | FURTHER REPORTS  |
|---|--|--|
| <p>Bajo Parana VTS zone consists of four Sectors.</p> <p><b>Sector 1.</b> (See Page ROS 2) From Km 310 to Km 376 of the Parana River<br/><b>VHF Ch. 12</b></p> <p><b>VIA:</b> San Nicolas Prefectura Naval Radio L6G</p> <p><b>Sector 2.</b> (See Page ROS 2 &amp; ROS 3). From Km 376 to Km 480 of the Parana River<br/><b>VHF Ch.14</b></p> <p><b>VIA:</b> Rosario Prefectura Naval Radio L6 I</p> <p><b>Sector 3.</b> (See Page ROS 3). From Km 480 to Km 568 of the Parana River.<br/><b>VHF Ch.12</b></p> <p><b>VIA:</b> Diamante Prefectura Naval Radio L6M</p> <p><b>Sector 4.</b> (See Page ROS 3). From Km 568 to Km 579 of the Parana River<br/><b>VHF Ch.12</b></p> <p><b>VIA:</b> Parana Prefectura Naval Radio L6N</p> <p><b>Note 2:</b> All vessels must maintain a continuous listening watch on MF Radio, VHF Ch. 16, and on the designated Sector Frequency.</p> | <p><b>1.</b> All vessels must obtain a Clearance from Bajo Parana Traffic Control Centre before entering or leaving the Bajo Parana VTS zone.</p> <p><b>VIA:</b> San Nicolas Prefectura Naval Radio L6G (Sector 1 VHF Ch. 12)<br/>Rosario Prefectura Naval Radio L6I (Sector 2 VHF Ch. 14)<br/>Diamante Prefectura Naval Radio L6M (Sector 3 VHF Ch. 12)<br/>Parana Prefectura Naval Radio L6N (Sector 4 VHF Ch. 12)</p> <p><b>Responsible Authority.</b></p> <p><i>PREFECTURA NAVAL ARGENTINA</i> through <b>Bajo Parana Traffic Control Centre.</b></p> <p>San Nicolas Prefectura Naval Radio L6G (Sector 1)<br/>Tel/Fax: 54 03 461-42 36 93<br/>e-Mail: sannicolas@prefecturanaval.gov.ar<br/>Address: Puerto Nuevo s/n Provincia de Buenos Aires, CP2900</p> <p>Rosario Prefectura Naval Radio L6I (Sector 2)<br/>Tel/Fax: 54-03 41 47 20 343<br/>e-Mail: rosario@prefecturanaval.gov.ar<br/>Address: Av.Belgrano 321, Rosario Provincia de Santa Fe, CP2000</p> <p>Diamante Prefectura Naval Radio L6M (Sector 3)<br/>Tel/Fax: 54 03 43 49 81 117<br/>e-Mail: diamante@prefecturanaval.gov.ar<br/>Address: 9 de Julio 472. Diamante, Pcia, Entre Rios, CP3105</p> <p>Parana Prefectura Naval Radio L6N (Sector 4)<br/>Tel/Fax: 54 03 43 43 10 201<br/>Address: Guemes y Liniers s/n, Parana, Pcia.E.Rios, CP3100</p> <p>If contact with local VTS cannot be made, vessels may contact (e-mail) kstm@prefecturanaval.gov.ar</p> <p>Vessels may obtain information concerning regulations applicable to the area from PNA Maritime Ordinances and Publications.</p> | <p><b>NOTE:</b> Pilotage is compulsory for all Sectors of the Baja Parana VTS Zone.</p> <p>Reporting is made under the direction of the designated Pilot.</p> <p>Vessels entering Baja Parana VTS Zone from upstream or downstream shall report position at the following points:</p> <p><b>Giving:</b> IMO SRS items: Alpha, Bravo, Delta, Echo, Foxtrot</p> <p><b>Via:</b> San Nicolas Prefectura Naval Radio L6G (Sector 1 VHF Ch. 12)<br/>Rosario Prefectura Naval Radio L6I (Sector 2 VHF Ch. 14)<br/>Diamante Prefectura Naval Radio L6M (Sector 3 VHF Ch. 12)<br/>Parana Prefectura Naval Radio L6N (Sector 4 VHF Ch. 12)</p> <p><b>Sector 1.</b><br/>Abeam <b>(A)</b> Km 301, <b>(B)</b> Km 376 of the Parana River<br/><b>VHF Ch. 12.</b></p> <p><b>Sector 2.</b><br/>Abeam <b>(D)</b> Km 376, <b>(E)</b> Km 400, <b>(F)</b> Km 412, <b>(G)</b> Km 418, <b>(H)</b> Km 430, <b>(I)</b> Km 455, <b>(J)</b> Km 480 of the Parana River <b>VHF Ch. 14</b></p> <p><b>Sector 3.</b><br/>Abeam <b>(K)</b> Km 480, <b>(L)</b> Km 533, <b>(M)</b> Km 568 of the Parana River <b>VHF Ch. 12</b></p> <p><b>Sector 4.</b><br/>Abeam <b>(N)</b> Km 568, <b>(O)</b> Km 579 of the Parana River <b>VHF Ch. 12</b></p> <p><b>Services offered.</b><br/>Information on Safety of Navigation, Sea Conditions and Weather Forecasts <b>VHF Ch. 15</b></p> <p><b>Pilotage.</b><br/>Is compulsory for all vessels.</p> |