

VHF PROCEDURES	SERVICES OFFERED	PILOTAGE
<p>All vessels within 20 nm of Taipei Port Control must maintain a continuous listening watch on VHF CH 68.</p> <p><b>Call sign:</b> 'Taipei Port Control'</p> <p>Permission to change frequency or to end VHF CH 68 listening watch must first be obtained from Taipei Port Control.</p> <p><b>REPORTS</b></p> <p>Inbound and Outbound Vessels must call Taipei Port Control on VHF CH 68 when entering or leaving Taipei Port Area.</p> <p><b>Anchoring:</b></p> <p>Vessels anchoring or heaving up anchor must report to Taipei Port Control on VHF CH 68.</p> <p><b>Changing berth:</b></p> <p>Any vessel either leaving a berth or arriving at a new berth must report to Taipei Port Control on VHF CH 68 giving IMO SRS ITEMS: Alpha, Bravo (departure/arrival time), Delta and Oscar.</p> <p><b>Incident Reports:</b></p> <p>All vessels are required to immediately report any incident or accident affecting safety or the environment to Taipei Port Control on VHF CH 68.</p>	<p><b>Information Service:</b></p> <ol style="list-style-type: none"> <li>Information concerning the safe passage of vessels through the Taipei Port area.</li> <li>General information on fairway and traffic conditions including - casualties, dredging and navigation warnings.</li> <li>Incidental assistance with navigation.</li> <li>Ordering fire fighting services, pilotage or ambulance.</li> </ol> <p><b>Contact Taipei Port Control Via:</b></p> <p>VHF CH 68 Tel: (02) 26196010 or (02) 26196057 Fax: (02) 86301939</p> <p><b>Anchorage:</b></p> <p>Vessels over 500 GRT must obtain permission from Taipei Port Signal Control before anchoring.</p>	<p><b>NOTE:</b> Pilotage is compulsory for vessels over 500 GRT.</p> <p><b>Exemptions R.O.C flag vessel as follows:</b></p> <ol style="list-style-type: none"> <li>Warships</li> <li>Government vessels</li> <li>Pilot Boats</li> <li>Vessel of less than 1,000 GRT</li> <li>Ferry Boats</li> <li>Yachts</li> <li>Others: Coasters or working vessels by permission.</li> </ol> <p><b>Taipei Port Pilot</b></p> <p><b>Inbound:</b> Vessels should call Pilots 6 nautical miles off pilot Station</p> <p><b>Outbound:</b> Vessels should call Pilots 2 hours before departure</p> <p><b>Contact Taipei Port Pilot Via:</b></p> <p>VHF CH 11 Tel: (02) 26196291 (office hours only) Fax: (02) 86301719</p>